


Ball & Beam **GBB1004**

USER'S GUIDE & EXPERIMENT MANUAL



Fourth Edition, January, 2010

Headquarter

香港九龍清水灣香港科技大學新翼大樓 3639 號
Room 3639, Annex Building, HKUST,
Clear Water Bay, Kowloon, Hong Kong
Tel.: (852) 2358 1033, (852) 2719 8310
Fax: (852) 2719 8399

Googol Shenzhen

深圳市南山區高新科技園深港產學研基地西二樓
2/F, West Wing, IER Building, High-Tech Park
Nanshan, Shenzhen, China
Tel: (86)755 2697 0817; (86)755 2697 0838
Fax: (86)755 2697 0846
<http://www.googoltech.com.cn>

TABLE OF CONTENTS

| | |
|--|------------------|
| COPYRIGHT STATEMENT | I |
| DISCLAIMER | I |
| TRADEMARKS | I |
| <u>TABLE OF CONTENTS</u> | <u>II</u> |
| <u>FOREWORD</u> | <u>1</u> |
| WELCOME TO THE WORLD OF GOOGOL TECHNOLOGY EDUCATIONAL PRODUCTS | 1 |
| FOR ADDITIONAL INFORMATION ABOUT GOOGOL TECHNOLOGY PRODUCTS | 1 |
| FOR TECHNICAL OR CUSTOMER SUPPORT | 1 |
| <u>READ THIS FIRST</u> | <u>2</u> |
| ABOUT THIS MANUAL | 2 |
| INTENDED AUDIENCE | 2 |
| PREREQUISITES | 2 |
| CONTENTS DESCRIPTION | 2 |
| CONVENTIONS USED IN THE DOCUMENT | 3 |
| <u>CHAPTER 1 OVERVIEW</u> | <u>4</u> |
| 1.1 OUTLINE | 4 |
| 1.2 BALL & BEAM FEATURES & BENEFITS | 4 |
| 1.3 BALL & BEAM FUNCTIONAL COMPONENTS | 4 |
| 1.3.1 MECHANICAL PLANT | 6 |
| 1.3.2 INTELLIGENT DRIVE | 6 |
| 1.3.3 PC-BASED CONTROL SOFTWARE | 7 |
| <u>CHAPTER 2 GETTING STARTED</u> | <u>8</u> |
| 2.1 THE BALL & BEAM PACKAGE | 8 |
| 2.2 ELEMENTS YOU NEED | 8 |
| 2.3 GETTING STARTED IN MATLAB SIMILINK | 8 |
| 2.3.1 STEP 1: CONNECTING BALL&BEAM | 9 |

| | | |
|---|---|------------------|
| 2.3.2 | STEP 2: INSTALLING BALL&BEAM CONTROL TOOLBOX | 9 |
| 2.3.3 | STEP 3: SET PARAMETERS | 12 |
| <u>CHAPTER 3</u> | | <u>18</u> |
| SYSTEM MODELING | | |
| 3.1 | MECHANICAL MODEL OF BALL&BEAM | 18 |
| 3.2 | MODELING THE BALL AND BEAM EXPERIMENT IN SIMULINK | 19 |
| 3.3 | ELECTRICAL MODEL | 24 |
| 3.4 | CONTROL MODEL | 26 |
| <u>CHAPTER 4</u> | | <u>29</u> |
| SAMPLE EXPERIMENTS | | |
| 4.1 | DATA COLLECTION AND PROCESSING | 29 |
| 4.2 | OPEN-LOOP MODEL OF BALL&BEAM SYSTEM | 31 |
| 4.3 | BALL AND BEAM CONTROL USING PID | 33 |
| 4.3.1 | PROPORTIONAL CONTROL | 33 |
| 4.3.2 | PROPORTIONAL-DERIVATIVE CONTROL | 36 |
| 4.3.3 | ANALYSIS OF PID CONTROL | 38 |
| 4.4 | ROOT LOCUS METHOD | 41 |
| 4.5 | FREQUENCY RESPONSE METHOD | 49 |
| 4.6 | USER DEFINE CONTROLLERS | 55 |
| <u>CHAPTER 5</u> | | <u>56</u> |
| TROUBLESHOOTING | | |
| <u>APPENDIX A</u> | | <u>58</u> |
| REAL CONTROL IN IPM MOTION STUDIO | | |
| STEP BY STEP INSTALLATION USING IPM MOTION STUDIO | | 58 |
| STEP 1: INSTALLING CONTROL SOFTWARE | | 58 |
| STEP 2: ESTABLISHING COMMUNICATION | | 59 |
| STEP 3: RUNNING THE DEMO PROGRAM | | 59 |
| STEP 4: ANALYZING RESULTS OF THE DEMO EXPERIMENT | | 63 |
| <u>APPENDIX B</u> | | <u>66</u> |
| LISTING OF DEMO | | |
| PART ONE: VARIABLES DECLARATION | | 66 |
| PART TWO: THE MAIN CONTROL LOOP | | 67 |
| <u>APPENDIX C</u> | | <u>72</u> |
| ELECTRIC DIAGRAM | | |